Panasonic

Operating Instructions

Interactive Pointer Commercial Use




FT-PNT100

Thank you for purchasing this Panasonic product.

- · Before using this product, please read this instructions and "LightPenII: Operation Manual" completely, and save this manual for future use.
 - 3) Pressing the button once has the same function as left-clicking a mouse. Press and hold the button to drag. In pen mode, you can draw lines

Names



Bofore using the pointer

Screw the long rod into the body of the pointer until it is secure. Install batteries.

How to use the pointer

While pressing the button, when the LED lights, the infrared ray at the end of the rod also lights. This is sensed by the infrared ray sensor on the front of the projector, and the location of the tip of the pen is detected.


- 1) Press the power button to turn the power on.
- 2) Place the tip of the pointer anywhere on the screen.

Attention

On status will consume battery power. When not in use, press the power button to turn the power off. (Press the button to confirm that the LED does not light.)

Installing and Removing Batteries

- 1. Rotate the part as shown in the figure.
- 2. Install 2 AAA/R03 or AAA/LR03 type batteries.



Disposal of Old Equipment

Only for European Union and countries with recycling systems



This symbol on the products, packaging, and/or accompanying documents means that used electrical and electronic products must not be mixed with general household waste. For proper treatment, recovery and recycling of old products, please take them to applicable collection points in accordance with your national legislation.

By disposing of them correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment.

For more information about collection and recycling, please contact your local authority. Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.

Panasonic

取扱説明書

インタラクティブポインター (業務用)

品番 ET-PNT100



このたびは、パナソニック製品をお買い上げいただき、まことにありがとうございます。この「取扱説明書」および「LightPenll; 操作説明書」をよくお読みのうえ、正しい操作を行ってください。そのあと大切に保管してください。

各部の名称



ご使用の前に

ロッドをポインター本体にしっかりとねじ込んでください。電池が必要です。

使用方法

ボタンを押している間、LED が点灯するとともに、ロッド先端から赤外線が発光します。これをプロジェクターの前面にある赤外線センサーが感知し、ポインターの先端位置を検出します。

- 1) 電源ボタンを押して、電源をオンします。
- ポインターの先端をスクリーン上の任意の場所に置きます。
- 3) ボタンを押すとマウスの左クリックと同じ働きをします。ボタンを押し続けることでドラッグすることができます。ペンモードの時に、線を引くことができます。

お願い

電源オンの状態では電池を消耗します。無駄に電池を消耗させないため、使わない時は、電源ボタンを押して、電源をオフの状態(ボタンを押して LED が点灯しないことを確認) にして保管してください。

電池を入れる、取り出す

- 1. ポインターの図の部分を回して開ける。
- 2. 単四形乾電池 (2個) を図の向きに入れる。



ヨーロッパ連合以外の国の廃棄処分に関する情報



これらのシンボルマークは EU 域内でのみ有効です。 製品を廃棄する場合には、最寄

製品を廃棄する場合には、最奇りの市町村窓口、または販売店で正しい廃棄方法をお問い合わせください。

パナソニック コネクト株式会社

〒 571-8503 大阪府門真市松葉町 2番 15号

電話 00.0120-872-601

JAPANESE

© Panasonic Connect Co., Ltd. 2022

SS0212ZF2062-PT TQZJ712-2