

					HTQ20 SERIES
CATEGORY	EndPoint	body1	body2	Parameter	HTQ20
Setting		network-wireless-ipv4-subnetmask network-wireless-ipv4-default-gateway			GET only GET only
	/api/{version}/light-output	light-output-state light-output-max			GET only GET only
	/api/{version}/operating-mode	operating-mode-state		normal eco quiet quiet1 quiet2 user1 user2 user3	✓ ✓ ✓ ✓ ✓ ✓
	/api/{version}/clock	clock-year clock-month clock-day clock-hour clock-minute clock-second			GET only GET only GET only GET only GET only GET only
	/api/{version}/command-protect	command-protect-state		disable enable-md5 enable-sha-256	✓ ✓ ✓
	/api/{version}/schedule	schedule-state		on off	✓ ✓
	/api/{version}/timers	timers	timer-id timer-state	on off	
	/api/{version}/timers/{timer-id}	timer-id timer-state		on off	
	/api/{version}/pjlink	pjlink-state pjlink-password		on off	 PUT only
	/api/{version}/crestron	crestron-state		on off	GET only GET only
	/api/{version}/update	update-firmware-progress update-firmware			GET only PUT only
	/api/{version}/sound	sound-volume			
	/api/{version}/https-csr-key	update-time rsa-length			GET only GET only
	/api/{version}/https-csr-request	https-csr-host-name https-csr-country-code https-csr-prefectures-name https-csr-city-name https-csr-organization-name https-csr-department-name			PUT only PUT only PUT only PUT only PUT only PUT only
	/api/{version}/https-csr-file				GET only
	/api/{version}/https-intermediate-certificate	state			PUT only
	/api/{version}/https-server-certificate	state			PUT only
	/api/{version}/error	errors	error-kind error-category error-code error-message	no error warning error none fan light temperature cover open filter other	GET only GET only GET only GET only GET only GET only GET only GET only GET only GET only GET only
Status	/api{version}/lights	lights	light-id light-name light-state light-runtime		GET only GET only GET only GET only
	/api/{version}/lights/{light-id}	light-id light-name light-state light-runtime			GET only GET only GET only GET only
	/api/{version}/device-information	model-name serial-no projector-name display-name mac-address power-on-times device-runtime ac-voltage			GET only GET only GET only GET only GET only GET only GET only
	/api/{version}/version	main-version sub-version network-version			GET only
	/api/{version}/temperatures	temperatures	temperature-id temperature-name temperature-celsius temperature-fahrenheit		GET only GET only GET only GET only
	/api/{version}/temperatures/{temperature-id}	temperature-id temperature-name temperature-celsius temperature-fahrenheit			GET only GET only GET only GET only
	/api/{version}/packet-information	packet-info-collision packet-info-recv-packet packet-info-recv-packet-error packet-info-recv-packet-drop packet-info-recv-packet-overrun packet-info-recv-packet-frame packet-info-send-packet packet-info-send-packet-error packet-info-send-packet-drop packet-info-send-packet-overrun packet-info-send-packet-carrier			GET only GET only GET only GET only GET only GET only GET only GET only GET only GET only GET only GET only
	/api/{version}/fans	fans	fan-id fan-name fan-rotation-speed		GET only GET only GET only
	/api/{version}/fans/{fan-id}	fan-id fan-name fan-rotation-speed			GET only GET only GET only
	/api/{version}/angle-sensor	roll-angle pitch-angle			GET only GET only
	/api/{version}/signal	signal-information			GET only