					VMZ82 SERIES
CATEGORY	EndPoint	body1	body2	Parameter	VMZ82
Basic Control	/api/{version}/power	power-state		standby	✓
				on	✓
				reset	✓
	/api/{version}/input	input-state		COMPUTER	✓
				HDMI1	✓
				HDMI2	✓
				MEMORY VIEWER	✓
				NETWORK	✓
				DIGITAL LINK	✓
	/api/{version}/av-mute	av-mute-state		on	✓
				off	✓
	/api/{version}/freeze	freeze-state		on	✓
				off	✓
	/api/{version}/on-screen-display	osd-state		on	✓
				off	✓
	/api/{version}/test-pattern	test-pattern-state		white	✓
				colorbar-vertical	✓
				colorbar-horizontal	✓
				aspect	✓
				whitecross-black	✓
				blackcross-white	✓
				crosshatch-black	✓
				off	✓
	/api/{version}/back-color	back-color-state		blue	✓
				black	✓
				user1	✓
				default-logo	✓
Setting	/api/{version}/ntp	ntp-sync		on	✓
				off	✓
		ntp-server			✓
	/api/{version}/https	https-state		on	✓
				off	✓
	/api/{version}/network	network-ip-version		ipv4	✓
				ipv6	✓
				ipv4-and-ipv6	✓
		network-wired-dhcp		on	✓
				off	✓
		network-wired-ipv4-ip-address			✓
		network-wired-ipv4-subnetmask			✓
		network-wired-ipv4-default-gateway			✓
		network-wired-ipv4-dns1-ip-address			✓
		network-wired-ipv4-dns2-ip-address			✓
		network-wired-ipv6-auto-configuration		on	✓
				off	✓
		network-wired-ipv6-temporary-address		on	✓
				off	✓
		network-wired-ipv6-ip-address			✓
		network-wired-ipv6-prefix-length			✓
		network-wired-ipv6-default-gateway			✓
		network-wired-ipv6-link-local-address			GET only
		network-wired-ipv6-stateful-address			GET only
		network-wired-ipv6-stateless-addresses	network-wired-ipv6-stateless-address-id		GET only
			network-wired-ipv6-stateless-address		GET only
		network-wired-ipv6-temporary-addresses	network-wired-ipv6-temporary-address-id		GET only
			network-wired-ipv6-temporary-address		GET only
		network-wireless-state		on	✓
				off	✓
		network-wireless-key			PUT only
		network-wireless-ssid			GET only
		network-wireless-authentication			GET only
		network-wireless-encryption			GET only
		network-wireless-ipv4-ip-address			GET only
		network-wireless-ipv4-subnetmask			GET only
		network-wireless-ipv4-default-gateway			GET only
	/api/{version}/light-output	light-output-state			✓
	/api/{version}/operating-mode	operating-mode-state		normal	✓
				eco	✓
				quiet1	✓
				quiet2	✓
				user1	✓
	/api/{version}/clock	clock-year			✓
		clock-month			✓
		clock-day			✓
		clock-hour			✓
		clock-minute			✓
		clock-second			✓
	/api/{version}/command-protect	command-protect-state		disable	✓
				enable-md5	✓
	/api/{version}/schedule	schedule-state		on	✓
				off	✓
	/api/{version}/pjlink	pjlink-state		on	✓
				off	✓
		pjlink-password			PUT only
	/api/{version}/crestron	crestron-state		on	✓
				off	✓
	/api/{version}/update	update-firmware-progress			GET only
		update-firmware			PUT only
	/api/{version}/sound	sound-volume			✓
	/api/{version}/https-csr-key	update-time			GET only
		rsa-length			GET only
	/api/{version}/https-csr-request	https-csr-host-name			PUT only
		https-csr-country-code			PUT only
		https-csr-prefectures-name			PUT only
		https-csr-city-name			PUT only
		https-csr-organization-name			PUT only
		https-csr-department-name			PUT only
	/api/{version}/https-csr-file				GET only
	/api/{version}/https-intermediate-certificate	state			PUT only
	/api/{version}/https-server-certificate	state			PUT only
Status	/api/{version}/error	errors	error-kind	no error	GET only
				warning	GET only
				error	GET only
			error-category	none	GET only
				fan	GET only
				light	GET only
				temperature	GET only
				cover open	GET only
				filter	GET only
				other	GET only
			error-code		GET only
			error-message		GET only
	/api{version}/lights	lights	light-id		GET only
			light-name		GET only
			light-state		GET only
			light-runtime		GET only
	/api/{version}/lights/{light-id}	light-id			GET only
		light-name			GET only
		light-state			GET only
		light-runtime			GET only
	/api/{version}/device-information	model-name			GET only
		serial-no			GET only
		projector-name			GET only
		mac-address			GET only
		power-on-times			GET only
		device-runtime			GET only
	/api/{version}/version	main-version			GET only
		sub-version			GET only
	/api/{version}/temperatures	temperatures	temperature-id		GET only
			temperature-name		GET only
			temperature-celsius		GET only
			temperature-fahrenheit		GET only
	/api/{version}/temperatures/{temperature-id}	temperature-id			GET only
		temperature-name			GET only
		temperature-celsius			GET only
		temperature-fahrenheit			GET only
	/api/{version}/packet-information	packet-info-collision			GET only
		packet-info-recv-packet			GET only
		packet-info-recv-packet-error			GET only
		packet-info-recv-packet-drop			GET only
		packet-info-recv-packet-overrun			GET only
		packet-info-recv-packet-frame			GET only
		packet-info-send-packet			GET only
		packet-info-send-packet-error			GET only
		packet-info-send-packet-drop			GET only
	/api/{version}/fans	fans	fan-id		GET only
			fan-name		GET only
			fan-rotation-speed		GET only
	/api/{version}/fans/{fan-id}	fan-id			GET only
		fan-name			GET only
		fan-rotation-speed			GET only
	/api/{version}/angle-sensor	roll-angle			GET only
		pitch-angle			GET only
	/api/{version}/signal	signal-information			GET only