

## List of Compatible Device Models

### Multi Monitoring & Control Software 4.2

- As of October 2025 -

In using this software, bear in mind that the items whose settings must be selected for the projectors and the functions that can be used may differ from one projector model to another. While referring to the table below, check out that projector models are compatible with the software before using them.

■ A list of compatible flat panel display models is available for download from the Panasonic website (<https://docs.connect.panasonic.com/prodisplays/download/software>).

#### List of device models

##### ■ Projector\*1

NTN91000*2	72	PT-DW7000*3	41
NTN91001*2	72	PT-DW730	38
NTN91002*2	71	PT-DW740	37
NTN91003*2	71	PT-DW750	22
PT-CMZ50	28	PT-DW830	22
PT-D10000*3	40	PT-DW8300	36
PT-D12000	35	PT-DW90XE*3	36
PT-D3500*3	42	PT-DX100	22
PT-D4000	42	PT-DX500	39
PT-D5000	38	PT-DX610	37
PT-D5600*3	42	PT-DX800	38
PT-D5700	42	PT-DX810	37
PT-D6000	38	PT-DX820	22
PT-D7700*3	41	PT-DZ10K	21
PT-DS100XE*3	36	PT-DZ110XE*3	36
PT-DS12K	21	PT-DZ12000	35
PT-DS20K	21	PT-DZ13K	21
PT-DS20K2	20	PT-DZ16K	21
PT-DS8500	36	PT-DZ16K2	20
PT-DW100	35	PT-DZ21K	21
PT-DW10000*3	40	PT-DZ21K2	20
PT-DW105XEA*4	36	PT-DZ570	39
PT-DW11K	21	PT-DZ6700	38
PT-DW17K	21	PT-DZ6710	38
PT-DW17K2	20	PT-DZ680	37
PT-DW5000*3	42	PT-DZ770	37
PT-DW5100	42	PT-DZ780	22
PT-DW530	39	PT-DZ870	22
PT-DW6300	38	PT-DZ8700	36
PT-DW640	37	PT-EW530	46

PT-EW540	43	PT-LB332*4	66
PT-EW550	44	PT-LB353*4	66
PT-EW551*4	45	PT-LB355*4	65
PT-EW630	46	PT-LB356*4	64
PT-EW640	43	PT-LB360	67
PT-EW650	44	PT-LB382	66
PT-EW651*4	45	PT-LB383	66
PT-EW730	43	PT-LB385*4	65
PT-EX12K	47	PT-LB386*4	64
PT-EX16K	47	PT-LB412	66
PT-EX500	46	PT-LB423	66
PT-EX510*4	43	PT-LB425	65
PT-EX520*4	44	PT-LB426	64
PT-EX521*4	45	PT-LB90NT	69
PT-EX600	46	PT-LMW420	29
PT-EX610	43	PT-LMW460	29
PT-EX620	44	PT-LMX420	29
PT-EX621*4	45	PT-LMX460	29
PT-EX800	43	PT-LMZ420	29
PT-EZ57*4	44	PT-LMZ460	29
PT-EZ570	46	PT-LRW35*4	63
PT-EZ580	43	PT-LRZ35*4	63
PT-EZ590	44	PT-LW25H	68
PT-EZ591*4	45	PT-LW280	67
PT-EZ770	43	PT-LW312	66
PT-F100NT	61	PT-LW330	67
PT-F200NT	61	PT-LW333*4	66
PT-F300	60	PT-LW335*4	65
PT-F300NT	60	PT-LW336*4	64
PT-FRQ50	18	PT-LW362	66
PT-FRQ60	18	PT-LW373	66
PT-FRZ50	19	PT-LW375	65
PT-FRZ55	19	PT-LW376	64
PT-FRZ60*4	19	PT-LX26H	68
PT-FW100NT	61	PT-LX30H	68
PT-FW300	60	PT-LZ370	62
PT-FW300NT	60	PT-MW530	26
PT-FW430	59	PT-MW630	26
PT-FW530	45	PT-MW730	26
PT-FX400	59	PT-MZ10K	24
PT-FX500*4	45	PT-MZ11K	23
PT-FZ570	45	PT-MZ13K	24
PT-JW130F*4	72	PT-MZ14K	23
PT-JW130G*4	72	PT-MZ16K	24
PT-JW130H*4	72	PT-MZ17K	23
PT-JX200F*4	71	PT-MZ20K	23
PT-JX200G*4	71	PT-MZ570	26
PT-JX200H*4	71	PT-MZ670	26
PT-LB1	70	PT-MZ680	25
PT-LB1V	70	PT-MZ682*4	25
PT-LB2	70	PT-MZ770	26
PT-LB2V	70	PT-MZ780	25
PT-LB3	70	PT-MZ782	25
PT-LB330	67	PT-MZ880	25

PT-MZ882	25	PT-RZ890	15
PT-RCQ10	14	PT-RZ970	16
PT-RCQ80	14	PT-RZ990*4	15
PT-REQ10	11	PT-ST10	70
PT-REQ12	11	PT-TMW380	29
PT-REQ15	11	PT-TMX380	29
PT-REQ80*4	11	PT-TMZ400	29
PT-REZ10	11	PT-TW230	68
PT-REZ12	11	PT-TW231R	68
PT-REZ15	11	PT-TW250*4	67
PT-REZ80	11	PT-TW340*4	67
PT-RQ13K	10	PT-TW341R	67
PT-RQ18K	8	PT-TW342*4	67
PT-RQ22K	13	PT-TW343R	67
PT-RQ25K	8	PT-TW350*4	66
PT-RQ32K	9	PT-TW351R	66
PT-RQ35K	7	PT-TW370*4	65
PT-RQ35K2	7	PT-TW371R	65
PT-RQ50K	6	PT-TW380*4	64
PT-RQ6	11	PT-TW381R	64
PT-RQ7	11	PT-TX310*4	67
PT-RS11K	10	PT-TX312*4	67
PT-RS20K	13	PT-TX320*4	66
PT-RS30K	9	PT-TX340*4	65
PT-RW330	34	PT-TX350*4	64
PT-RW430	33	PT-TX400*4	67
PT-RW620	16	PT-TX402*4	67
PT-RW630	17	PT-TX410*4	66
PT-RW730	16	PT-TX430*4	65
PT-RW930	16	PT-TX440*4	64
PT-RX110	16	PT-VMW50	30
PT-RZ12K	10	PT-VMW51	28
PT-RZ120	14	PT-VMW60*4	30
PT-RZ14K	8	PT-VMW61*4	28
PT-RZ16K	12	PT-VMZ40*4	30
PT-RZ17K	8	PT-VMZ41*4	28
PT-RZ21K	13	PT-VMZ5ES	27
PT-RZ24K	8	PT-VMZ50	30
PT-RZ31K	9	PT-VMZ51	28
PT-RZ34K	7	PT-VMZ51S*4	28
PT-RZ34K2	7	PT-VMZ6ST	27
PT-RZ370	34	PT-VMZ60	30
PT-RZ470	33	PT-VMZ61	28
PT-RZ475	32	PT-VMZ62	27
PT-RZ570	31	PT-VMZ7ST	27
PT-RZ575	31	PT-VMZ71	28
PT-RZ6	11	PT-VMZ72	27
PT-RZ660	16	PT-VMZ82	27
PT-RZ670	17	PT-VW330	54
PT-RZ690	15	PT-VW340*4	57
PT-RZ7*4	11	PT-VW345N	49
PT-RZ770	16	PT-VW350*4	57
PT-RZ790*4	15	PT-VW355N	49
PT-RZ870	17	PT-VW360	56

PT-VW430	53
PT-VW431D	53
PT-VW435N	55
PT-VW440	53
PT-VW530*4	51
PT-VW535N	49
PT-VW540*4	50
PT-VW545N	48
PT-VX400	54
PT-VX400NT	55
PT-VX405*4	53
PT-VX406*4	58
PT-VX41	54
PT-VX410*4	57
PT-VX415N	49
PT-VX42*4	57
PT-VX420*4	57
PT-VX421*4	58
PT-VX425N	49
PT-VX430	56
PT-VX431K	56
PT-VX45*4	53
PT-VX46*4	58
PT-VX50*4	51
PT-VX500	53
PT-VX501*4	53
PT-VX505N	55
PT-VX51*4	50
PT-VX510	53
PT-VX60*4	51
PT-VX600*4	51
PT-VX605N	49
PT-VX61*4	50
PT-VX610	50
PT-VX615N	48
PT-VZ470*4	52
PT-VZ570*4	51
PT-VZ575N	49
PT-VZ580*4	50
PT-VZ585N	48
TH-D10000	40
TH-D3500	42
TH-D5600	42
TH-D7700	41
TH-DW10000	40
TH-DW5000	42
TH-DW7000	41

\*1: Note on model groups

The difference in the type of information that can be accessed for “rich information models” and “basic information models” is as follows.

○: Supported    ×: Not supported

Item	Model categorization based on accessible information difference	
	Rich information model	Basic information model
Group Name	○	○
IP Address	○	○
Shutter (AV Mute)	○	○
Model Name	○	○
Serial Number	○*	×
Selected input	○	○
Power	○	○
Selected LIGHT	○*	×
LIGHT Power / Operating mode	○	×
Signal Freq.	○	×
Main Version	○	×
Network Version	○*	×
Power on hours	○	○*
Temperature	○*	×
LIGHT status	○*	○*
Fan status	○*	×

\* May not be accessible depending on the device.

\*2: Model number of product sold in Japan. This will differ for products sold in other regions.

\*3: Model number of product sold in regions other than Japan. This will differ for products sold in Japan.

\*4: Not sold in Japan.

## Notes

The software is not compatible with any device models not appearing in this “Device model list.”

## Peripheral device list

### ■ Peripheral devices

#### Media Processor FMP Series

ET-FMP50 . . . . .	73	ET-SBFMP10 . . . . .	73
ET-FMP20 . . . . .	73		

#### Network camera

Panasonic BB-S Series, DG-S Series, WV-S Series, AW-UN70 Series, AW-HN130 Series, AW-HN40 Series, AW-HE130 Series, AW-HE40 Series, and AW-HR140 network cameras are supported. Allows the video shown on a display (projector or flat-panel display) to be checked remotely through a camera.

## PT-RQ50K

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/E/X/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	dispadmin* <sup>1</sup>
		Password	@Panasonic* <sup>2</sup>
	PJLink	Password	@Panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		1024
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		○
	Remote preview function or remote preview lite		○
	Simultaneous multi-device firmware update function		○
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-RQ35K2 / PT-RZ34K2 / PT-RQ35K / PT-RZ34K

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/E/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	Set by user* <sup>1</sup>
		Password	Set by user* <sup>1</sup>
	PJLink	Password	Set by user* <sup>1</sup>
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		ON
			—
			1024
			ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		○
	Remote preview function or remote preview lite		○
	Simultaneous multi-device firmware update function		×
	Push notification function		○

\*1: The username and password of the administrator account must be configured.

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/E/EJ/X/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	Set by user* <sup>1</sup>
		Password	Set by user* <sup>1</sup>
	PJLink	Password	Set by user* <sup>1</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		1024
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		○
	Remote preview function or remote preview lite		○
	Simultaneous multi-device firmware update function		○
	Push notification function		○

\*1: The username and password of the administrator account must be configured.



## PT-RQ32K / PT-RZ31K / PT-RS30K

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		1024
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		○* <sup>3</sup>
	Push notification function		○* <sup>4</sup>

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

\*3: The PT-RS30K does not support the simultaneous multi-device firmware update function.

\*4: The PT-RS30K does not support error information push notification.

## PT-RQ13K / PT-RZ12K / PT-RS11K

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		1024
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-REQ15 / PT-REQ12 / PT-REQ10 / PT-REQ80

■ PT-REZ15 / PT-REZ12 / PT-REZ10 / PT-REZ80

■ PT-RQ7 / PT-RQ6 / PT-RZ7 / PT-RZ6

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/E/EJ/J/UG/(blank), lens: (blank)/L, cabinet color: B/W)

Model group: **Rich information model**

○: Supported    X: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	Set by user* <sup>1</sup>
		Password	Set by user* <sup>1</sup>
	PJLink	Password	Set by user* <sup>1</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		1024
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		X
	Maintenance log save function		○
	Contents list delivery function		X
	Wireless settings display function		○
	DATA CLONING		○
	Remote preview function or remote preview lite		○
	Simultaneous multi-device firmware update function		○
	Push notification function		○

\*1: The username and password of the administrator account must be configured.

## PT-RZ16K

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	Set by user*1
		Password	Set by user*1
	PJLink	Password	Set by user*1
Projector settings	Network standby		—
	Network control		
		WEB control	ON
		Command control	—
		WEB port / Command port	1024
		PJLink control	ON
	ECO management		
		Standby mode	—
Standby mode		Normal	
Monitoring and control functions	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		○
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		○
	Push notification function		○

\*1: The username and password of the administrator account must be configured.

## PT-RQ22K / PT-RZ21K / PT-RS20K

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	dispadmin* <sup>1</sup>
		Password	@Panasonic* <sup>2</sup>
	PJLink	Password	@Panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		1024
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		○
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		○* <sup>3</sup>
	Push notification function		○* <sup>4</sup>

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

\*3: The PT-RS20K does not support the simultaneous multi-device firmware update function.

\*4: The PT-RS20K does not support error information push notification.

# PT-RCQ10 / PT-RCQ80

# PT-RZ120

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: A/D/E/J/X/(blank), lens: (blank)/L, cabinet color: B/W)

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	dispadmin*1
		Password	@Panasonic*2
	PJLink	Password	@Panasonic*2
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		1024
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		○
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-RZ990 / PT-RZ890 / PT-RZ790 / PT-RZ690

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/(blank), lens: (blank)/L, cabinet color: B/W/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	Set by user* <sup>1</sup>
		Password	Set by user* <sup>1</sup>
	PJLink	Password	Set by user* <sup>1</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		1024
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		○
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: The username and password of the administrator account must be configured.

# PT-RZ970 / PT-RW930 / PT-RX110 / PT-RZ770 / PT-RW730 / PT-RZ660 / PT-RW620

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: A/D/E/J/T/U/(blank), lens: (blank)/L, cabinet color: B/K/W/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		ON
			—
			1024
			ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.



The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: A/D/E/J/T/U/(blank), lens: (blank)/L, cabinet color: B/K/W/(blank))

Model group: **Rich information model**

○: Supported    X: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		1024
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		X
	Maintenance log save function		○
	Contents list delivery function		X
	Wireless settings display function		X
	DATA CLONING		X
	Remote preview function or remote preview lite		X
	Simultaneous multi-device firmware update function		X
	Push notification function		X

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

# PT-FRQ60

# PT-FRQ50

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/W)

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	Set by user* <sup>1</sup>
		Password	Set by user* <sup>1</sup>
	PJLink	Password	Set by user* <sup>1</sup>
Projector settings	Network standby		—
	Network control		
		WEB control	ON
		Command control	—
		WEB port / Command port	—
		PJLink control	ON
	ECO management		
		Standby mode	—
		Standby mode	Normal
Monitoring and control functions	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		○
	Remote preview function or remote preview lite		○
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: The username and password of the administrator account must be configured.

## PT-FRZ60 / PT-FRZ50 / PT-FRZ55

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/W)

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	Set by user* <sup>1</sup>
		Password	Set by user* <sup>1</sup>
	PJLink	Password	Set by user* <sup>1</sup>
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		ON
			—
			—
			ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: The username and password of the administrator account must be configured.

## PT-DZ21K2 / PT-DS20K2 / PT-DW17K2 / PT-DZ16K2

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: A/D/E/J/T/U/(blank), lens: (blank)/L, cabinet color: B/K/W/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		1024
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-DZ21K / PT-DS20K / PT-DW17K / PT-DZ16K

■ PT-DZ13K / PT-DS12K / PT-DW11K / PT-DZ10K

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: A/D/E/J/T/U/(blank), lens: (blank)/L, cabinet color: B/K/W/(blank))

Model group: **Rich information model**

○: Supported   X: Not supported   —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
		WEB control	ON
		Command control	—
		WEB port / Command port	1024
		PJLink control	ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		X
	Maintenance log save function		○
	Contents list delivery function		X
	Wireless settings display function		X
	DATA CLONING		X
	Remote preview function or remote preview lite		X
	Simultaneous multi-device firmware update function		X
	Push notification function		X

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: A/D/E/J/T/U/(blank), lens: (blank)/L, cabinet color: B/K/W/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		ON
			—
			1024
			ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-MZ20K / PT-MZ17K / PT-MZ14K / PT-MZ11K

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/E/EJ/J/X/(blank), lens: L, cabinet color: B/W)

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	Set by user* <sup>1</sup>
		Password	Set by user* <sup>1</sup>
	PJLink	Password	Set by user* <sup>1</sup>
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		ON
			—
			1024
			ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		○
	Remote preview function or remote preview lite		○
	Simultaneous multi-device firmware update function		○
	Push notification function		○

\*1: The username and password of the administrator account must be configured.

## PT-MZ16K / PT-MZ13K / PT-MZ10K

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/E/J/X/(blank), lens: L, cabinet color: B/W)

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	dispadmin* <sup>1</sup>
		Password	@Panasonic* <sup>2</sup>
	PJLink	Password	@Panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		1024
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.



■ PT-MZ882 / PT-MZ782 / PT-MZ682

■ PT-MZ880 / PT-MZ780 / PT-MZ680

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/W)

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	Set by user* <sup>1</sup>
		Password	Set by user* <sup>1</sup>
	PJLink	Password	Set by user* <sup>1</sup>
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		ON
			—
			1024
			ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		○
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: The username and password of the administrator account must be configured.

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: A/D/J/(blank), lens: (blank)/L, cabinet color: (blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	dispadmin* <sup>1</sup>
		Password	@Panasonic* <sup>2</sup>
	PJLink	Password	@Panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		1024
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		○
	Wireless settings display function		○* <sup>3</sup>
	DATA CLONING		○
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

\*3: Optional wireless module (ET-WM300) is required.

## PT-VMZ5ES

## PT-VMZ82 / PT-VMZ72 / PT-VMZ62 / PT-VMZ7ST / PT-VMZ6ST

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	Set by user* <sup>1</sup>
		Password	Set by user* <sup>1</sup>
	PJLink	Password	Set by user* <sup>1</sup>
Projector settings	Network standby		—
	Network control		
		WEB control	ON
		Command control	—
		WEB port / Command port	—
		PJLink control	ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: The username and password of the administrator account must be configured.

# 

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	Set by user* <sup>1</sup>
		Password	Set by user* <sup>1</sup>
	PJLink	Password	Set by user* <sup>1</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		—
	PJLink control		ON
	ECO management		
	Standby mode		—
Standby mode		Normal	
Monitoring and control functions	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: The username and password of the administrator account must be configured.

**PT-LMZ460 / PT-LMZ420 / PT-LMW460 / PT-LMW420 / PT-LMX460 / PT-LMX420 / PT-TMZ400 / PT-TMW380 / PT-TMX380**

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/T/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	Set by user* <sup>1</sup>
		Password	Set by user* <sup>1</sup>
	PJLink	Password	Set by user* <sup>1</sup>
Projector settings	Network standby		—
	Network control		
		WEB control	ON
		Command control	—
		WEB port / Command port	—
		PJLink control	ON
	ECO management		
		Standby mode	—
		Standby mode	Normal
Monitoring and control functions	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: The username and password of the administrator account must be configured.

## PT-VMZ60 / PT-VMZ50 / PT-VMZ40 / PT-VMW60 / PT-VMW50

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	dispadmin* <sup>1</sup>
		Password	@Panasonic* <sup>2</sup>
	PJLink	Password	@Panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		—
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-RZ575 / PT-RZ570

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: A/D/J/T/(blank), cabinet color: B/W)

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		ON
			—
			—
			ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-RZ475

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		—
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○* <sup>3</sup>
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

\*3: If the temperature of the projector's surroundings is elevated, light output may be reduced in order to protect the projector unit. If this software is used for the brightness control of multiple projectors, please ensure that as far as possible the temperature of the surroundings is the same for all projectors.



## PT-RZ470 / PT-RW430

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/EA/U/(blank), cabinet color: K/W/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		—
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○* <sup>3</sup>
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

\*3: If the temperature of the projector's surroundings is elevated, light output may be reduced in order to protect the projector unit. If this software is used for the brightness control of multiple projectors, please ensure that as far as possible the temperature of the surroundings is the same for all projectors.

## PT-RZ370 / PT-RW330

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		ON
			—
			—
			ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-DZ12000 / PT-D12000 / PT-DW100

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/U/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not required (LAN terminal installed)* <sup>1</sup>
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>2</sup>
		Password	panasonic* <sup>3</sup>
	PJLink	Password	panasonic* <sup>3</sup>
Projector settings	Network standby		ON
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		1024
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		—
	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: Of the commercially available expansion boards, the ET-MD77NT network board is not supported.  
With expansion boards other than the ET-MD77NT, the network function on the expansion board side cannot be used (DVI, SDI, and other inputs are enabled).  
The ET-MD100SD4 digital signal input board (for dual link HD-SDI) is supported.

\*2: This is the user name provided at the time of shipment.

\*3: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

**PT-DZ8700 / PT-DS8500 / PT-DW8300 / PT-DZ110XE / PT-DS100XE / PT-DW90XE / PT-DW105XEA**

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/U/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby		—
	Network control		
		WEB control	ON
		Command control	—
		WEB port / Command port	—
		PJLink control	ON
	ECO management		
	Standby mode		—
			Normal
Monitoring and control functions	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		○
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/U/(blank), cabinet color: K/S/(blank), lens: (blank)/L)

Model group: **Rich information model**

○: Supported    X: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		—
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		X
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		X
	ECO management function		X
	Maintenance log save function		○
	Contents list delivery function		X
	Wireless settings display function		X
	DATA CLONING		X
	Remote preview function or remote preview lite		X
	Simultaneous multi-device firmware update function		X
	Push notification function		X

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-DZ6710 / PT-DZ6700 / PT-DW6300 / PT-D6000 / PT-D5000

■ PT-DW730 / PT-DX800

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/U/(blank), cabinet color: K/S/(blank), lens: (blank)/L)

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
		WEB control	ON
		Command control	—
		WEB port / Command port	—
		PJLink control	ON
	ECO management		
		Standby mode	—
		Standby mode	Normal
Monitoring and control functions	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-DZ570 / PT-DW530 / PT-DX500

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/U/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		—
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## TH-DW10000 / TH-D10000 / PT-DW10000 / PT-D10000

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/U)

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not required (LAN terminal installed)* <sup>1</sup>
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	user1
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		—
	Command control		—
	WEB port / Command port		—
	PJLink control		—
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		—
	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		×
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: Of the commercially available expansion boards, the ET-MD77NT network board is not supported.

With expansion boards other than the ET-MD77NT, the network function on the expansion board side cannot be used (DVI, SDI, and other inputs are enabled).

The ET-MD100SD4 digital signal input board (for dual link HD-SDI) is supported. (except for TH-D10000 and PT-D10000)

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.



## TH-D7700 / TH-DW7000 / PT-D7700 / PT-DW7000

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/U, cabinet color: K/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Expansion board required*1
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	user1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		—
			—
			—
			—
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		—
	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		×
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: One of the following commercially available expansion boards with a network function is required.

Network board: ET-MD77NT

Digital signal input board (for SD-SDI): ET-MD77SD1

Digital signal input board (for HD-SDI): ET-MD77SD3

Digital signal input board (for DVI): ET-MD77DV

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-D5700 / PT-D4000 / PT-DW5100

■ TH-D5600 / PT-D5600 / TH-DW5000 / PT-DW5000

■ TH-D3500 / PT-D3500

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/U/(blank), lens: (blank)/L)

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	user1
		Password	panasonic*1
	PJLink	Password	panasonic*1
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		—
			—
			—
			—
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		—
	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		×
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■ PT-EZ770 / PT-EW730 / PT-EX800

## ■ PT-EZ580 / PT-EW640 / PT-EW540 / PT-EX610 / PT-EX510

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: A/D/J/K/T/Z/(blank), lens: (blank)/L)

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		ON
			—
			—
			ON
	ECO management		
	Standby mode		—
	Standby mode		Normal
Monitoring and control functions	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-EZ590 / PT-EW650 / PT-EW550 / PT-EX620 / PT-EX520 / PT-EZ57

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/K/T/(blank), lens: (blank)/L)

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		ON
			—
			—
			ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-EZ591 / PT-EW651 / PT-EW551 / PT-EX621 / PT-EX521

■ PT-FZ570 / PT-FW530 / PT-FX500

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/K/T/(blank), lens: (blank)/L)

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby		—
	Network control		
		WEB control	ON
		Command control	—
		WEB port / Command port	—
		PJLink control	ON
	ECO management		
		Standby mode	—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-EZ570 / PT-EW630 / PT-EW530 / PT-EX600 / PT-EX500

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		ON
			—
			—
			ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal, Network
	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

# ■ PT-EX16K      ■ PT-EX12K

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/U/(blank))

Model group: **Rich information model**

○: Supported    X: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		—
	PJLink control		ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		—
	Auto search (local network) function		X
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		X
	ECO management function		X
	Maintenance log save function		○
	Contents list delivery function		X
	Wireless settings display function		X
	DATA CLONING		X
	Remote preview function or remote preview lite		X
	Simultaneous multi-device firmware update function		X
	Push notification function		X

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-VZ585N / PT-VW545N / PT-VX615N

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/T/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		ON
			—
			—
			ON
	ECO management		
	Standby mode		Normal
Monitoring and control functions	Standby mode		—
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		○
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.



■ PT-VZ575N / PT-VW535N / PT-VX605N

■ PT-VW355N / PT-VX425N

■ PT-VW345N / PT-VX415N

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/T/Z/(blank))

Model group: **Rich information model**

○: Supported    X: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		ON
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		—
			—
			—
			—
	ECO management		
	Standby mode		—
	Standby mode		Normal
Monitoring and control functions	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		X
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		X
	Wireless settings display function		○
	DATA CLONING		X
	Remote preview function or remote preview lite		X
	Simultaneous multi-device firmware update function		X
	Push notification function		X

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-VZ580 / PT-VW540 / PT-VX610 / PT-VX61 / PT-VX51

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/K/K1/T/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		ON
			ON
			—
			ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/T/(blank))

Model group: **Rich information model**

○: Supported    X: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby		—
	Network control		ON
	WEB control Command control WEB port / Command port PJLink control	—	
		—	
		—	
		—	
	ECO management		
	Standby mode	—	
		Normal	
Monitoring and control functions	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-VZ470

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		ON
		WEB control	—
		Command control	—
		WEB port / Command port	—
		PJLink control	—
	ECO management		
		Standby mode	—
Standby mode		Normal	
Monitoring and control functions	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■PT-VW440 / PT-VX510

■PT-VW431D

■PT-VW430 / PT-VX501 / PT-VX500 / PT-VX405 / PT-VX45

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/EA/KEA/U/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby		—
	Network control		ON
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		—
			—
			—
			—
	ECO management		
	Standby mode		—
	Standby mode		Network
Monitoring and control functions	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/EA/KEA/U/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby		—
	Network control		ON
	WEB control		—
	Command control		—
	WEB port / Command port		—
	PJLink control		—
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Network
	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported    X: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		ON
	WEB control		—
	Command control		—
	WEB port / Command port		—
	PJLink control		—
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Network
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		X
	ECO management function		X
	Maintenance log save function		○
	Contents list delivery function		X
	Wireless settings display function		X
	DATA CLONING		X
	Remote preview function or remote preview lite		X
	Simultaneous multi-device firmware update function		X
	Push notification function		X

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-VW360 / PT-VX430 / PT-VX431K

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/T/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	dispadmin* <sup>1</sup>
		Password	@Panasonic* <sup>2</sup>
	PJLink	Password	@Panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		ON
	WEB control		—
	Command control		—
	WEB port / Command port		—
	PJLink control		—
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.



The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/EA/J/T/Z/(blank))

Model group: **Rich information model**

○: Supported    X: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		ON
	WEB control		—
	Command control		—
	WEB port / Command port		—
	PJLink control		—
	ECO management		
	Standby mode		—
	Standby mode		Normal
Monitoring and control functions	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■ PT-VX421 ■ PT-VX406 / PT-VX46

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/EA/J/T/Z/(blank))

Model group: **Rich information model**

○: Supported    X: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		ON
	WEB control		—
	Command control		—
	WEB port / Command port		—
	PJLink control		—
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		X
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		X
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		X
	Wireless settings display function		X
	DATA CLONING		X
	Remote preview function or remote preview lite		X
	Simultaneous multi-device firmware update function		X
	Push notification function		X

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-FW430 / PT-FX400

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		ON
	WEB control		—
	Command control		—
	WEB port / Command port		—
	PJLink control		—
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-FW300NT / PT-FW300 / PT-F300NT / PT-F300

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		ON
	Network control		ON
	WEB control		—
	Command control		—
	WEB port / Command port		—
	PJLink control		—
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		—
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

# ■PT-FW100NT / PT-F100NT ■PT-F200NT

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	user1
		Password	No password set* <sup>1</sup>
	PJLink	Password	No password set* <sup>1</sup>
Projector settings	Network standby		ON
	Network control		
	WEB control		ON
	Command control		—
	WEB port / Command port		—
	PJLink control		—
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		—
	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		×
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the setting provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-LZ370

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		ON
	WEB control Command control WEB port / Command port PJLink control	—	
		—	
		—	
		—	
	ECO management		
	Standby mode	—	
		Normal	
Monitoring and control functions	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-LRZ35 / PT-LRW35

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: U/(blank))

Model group: **Basic information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	dispadmin* <sup>1</sup>
		Password	Set by user* <sup>1</sup>
	PJLink	Password	Set by user* <sup>1</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		—
	Command control		—
	WEB port / Command port		—
	PJLink control		—
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		×
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		×
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: The username and password of the administrator account must be configured.

■ PT-LB426 / PT-LB386 / PT-LB356 / PT-LW376 / PT-LW336

■ PT-TW381R / PT-TW380 / PT-TX440 / PT-TX350

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/T/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	Set by user* <sup>1</sup>
		Password	Set by user* <sup>1</sup>
	PJLink	Password	Set by user* <sup>1</sup>
Projector settings	Network standby		—
	Network control		ON
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		
	ECO management		
	Standby mode		—
	Standby mode		Normal
Monitoring and control functions	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: The username and password of the administrator account must be configured.



■ PT-LW375 / PT-LW335 / PT-LB425 / PT-LB385 / PT-LB355

■ PT-TW371R / PT-TW370 / PT-TX430 / PT-TX340

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/K/T/U/(blank))

Model group: **Basic information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin
		Password	admin1* <sup>1</sup>
	PJLink	Password	admin1* <sup>1</sup>
Projector settings	Network standby		—
	Network control		
		WEB control	—
		Command control	—
		WEB port / Command port	—
		PJLink control	—
	ECO management		
		Standby mode	—
	Standby mode		Normal
Monitoring and control functions	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		×
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		×
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-LW373 / PT-LW333 / PT-LB423 / PT-LB383 / PT-LB353

■ PT-TW351R / PT-TW350 / PT-TX410 / PT-TX320

■ PT-LW362 / PT-LW312 / PT-LB412 / PT-LB382 / PT-LB332

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/(blank))

Model group: **Basic information model**

○: Supported    X: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin
		Password	admin1* <sup>1</sup>
	PJLink	Password	admin1* <sup>1</sup>
Projector settings	Network standby		—
	Network control		
	WEB control		—
	Command control		—
	WEB port / Command port		—
	PJLink control		—
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		X
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		X
	Brightness control function		X
	ECO management function		X
	Maintenance log save function		X
	Contents list delivery function		X
	Wireless settings display function		X
	DATA CLONING		X
	Remote preview function or remote preview lite		X
	Simultaneous multi-device firmware update function		X
	Push notification function		X

\*1: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-LW330\*2 / PT-LW280\*2 / PT-LB360\*2 / PT-LB330\*2

■ PT-TW343R / PT-TW342 / PT-TX402 / PT-TX312

■ PT-TW341R\*2 / PT-TW340\*2 / PT-TW250\*2 / PT-TX400\*2 / PT-TX310\*2

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/J/(blank))

Model group: **Basic information model**

○: Supported    X: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin
		Password	admin1*1
	PJLink	Password	admin1*1
Projector settings	Network standby		—
	Network control		
	WEB control		—
	Command control		—
	WEB port / Command port		—
	PJLink control		—
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal
	Auto search (local network) function		X
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		X
	Brightness control function		X
	ECO management function		X
	Maintenance log save function		X
	Contents list delivery function		X
	Wireless settings display function		X
	DATA CLONING		X
	Remote preview function or remote preview lite		X
	Simultaneous multi-device firmware update function		X
	Push notification function		X

\*1: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

\*2: Only devices with serial numbers that start with "B" or "DB53" are supported.

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported    X: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		ON
	WEB control		—
	Command control		—
	WEB port / Command port		—
	PJLink control		—
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Network
	Auto search (local network) function		X
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		X
	ECO management function		X
	Maintenance log save function		○
	Contents list delivery function		X
	Wireless settings display function		X
	DATA CLONING		X
	Remote preview function or remote preview lite		X
	Simultaneous multi-device firmware update function		X
	Push notification function		X

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-LB90NT

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		ON
		WEB control	—
		Command control	—
		WEB port / Command port	—
		PJLink control	—
	ECO management		
		Standby mode	—
Standby mode		Normal	
Monitoring and control functions	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## PT-LB3 / PT-LB2V / PT-LB2 / PT-LB1V / PT-LB1 / PT-ST10

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1* <sup>1</sup>
		Password	panasonic* <sup>2</sup>
	PJLink	Password	panasonic* <sup>2</sup>
Projector settings	Network standby		—
	Network control		ON
	WEB control		—
	Command control		—
	WEB port / Command port		—
	PJLink control		—
	ECO management		
	Standby mode		—
	Standby mode		Normal
Monitoring and control functions	Auto search (local network) function		×
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		×
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		×
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/E/K/T/U, cabinet color: B/W)

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		ON
			—
			—
			ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal*3
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		○
	Contents list delivery function		×
	Wireless settings display function		○
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

\*3: When set to “Network” or “ECO”, information acquisition and control will be disabled.

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

\* Alphabet letters at end (place of destination: D/E/K/T/U, cabinet color: B/W)

Model group: **Rich information model**

○: Supported    ×: Not supported    —: Not available

			Setting / compatibility
Optional accessories	Expansion boards		Not used
Connection to projector	IP address		Only fixed IP address supported
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby		—
	Network control		
	<div> <div>WEB control</div> <div>Command control</div> <div>WEB port / Command port</div> <div>PJLink control</div> </div>		ON
			—
			—
			ON
	ECO management		
	Standby mode		—
Monitoring and control functions	Standby mode		Normal*3
	Auto search (local network) function		○
	Device status monitoring function (Simplified)		○
	Device location information registering function (Map monitoring function)		○
	Command transmission function		○
	Brightness control function		×
	ECO management function		○
	Maintenance log save function		×
	Contents list delivery function		×
	Wireless settings display function		○
	DATA CLONING		×
	Remote preview function or remote preview lite		×
	Simultaneous multi-device firmware update function		×
	Push notification function		×

\*1: This is the user name provided at the time of shipment.

\*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

\*3: When set to “Network” or “ECO”, information acquisition and control will be disabled.



## ■ ET-FMP50 / ET-FMP20 / ET-SBFMP10

The letters\* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

○: Supported    ✕: Not supported    —: Not available

		Setting / compatibility
Connection to Media Processor	IP address	Only fixed IP address supported
	User name	Set by user* <sup>1</sup>
	Password	Set by user* <sup>1</sup>
Functions	Media Processor power status display	○
	WEB control screen display	○
	Serial number display	○

\*1: The username and password of the account must be configured.