Panasonic

# List of Compatible Device Models

## Multi Monitoring & Control Software 5.1 or later

- As of September 2026 -

In using this software, bear in mind that the items whose settings must be selected for the projectors and the functions that can be used may differ from one projector model to another. While referring to the table below, check out that projector models are compatible with the software before using them.

■ **A list of compatible flat panel display models is available for download from the Panasonic website (https://docs.connect.panasonic.com/prodisplays/download/software).**

## List of device models

### ■ Projector*1


NTN91000*2 . . . 72
NTN91001*2 . . . 72
NTN91002*2 . . . 71
NTN91003*2 . . . 71
PT-CMZ50 . . . 28
PT-D10000*3 . . . 40
PT-D12000 . . . 35
PT-D3500*3 . . . 42
PT-D4000 . . . 42
PT-D5000 . . . 38
PT-D5600*3 . . . 42
PT-D5700 . . . 42
PT-D6000 . . . 38
PT-D7700*3 . . . 41
PT-DS100XE*3 . . . 36
PT-DS12K . . . 21
PT-DS20K . . . 21
PT-DS20K2 . . . 20
PT-DS8500 . . . 36
PT-DW100 . . . 35
PT-DW10000*3 . . . 40
PT-DW105XEA*4 . . . 36
PT-DW11K . . . 21
PT-DW17K . . . 21
PT-DW17K2 . . . 20
PT-DW5000*3 . . . 42
PT-DW5100 . . . 42
PT-DW530 . . . 39
PT-DW6300 . . . 38
PT-DW640 . . . 37
PT-DW7000*3 . . . 41
PT-DW730 . . . 38
PT-DW740 . . . 37
PT-DW750 . . . 22
PT-DW830 . . . 22
PT-DW8300 . . . 36
PT-DW90XE*3 . . . 36
PT-DX100 . . . 22
PT-DX500 . . . 39
PT-DX610 . . . 37
PT-DX800 . . . 38
PT-DX810 . . . 37
PT-DX820 . . . 22
PT-DZ10K . . . 21
PT-DZ110XE*3 . . . 36
PT-DZ12000 . . . 35
PT-DZ13K . . . 21
PT-DZ16K . . . 21
PT-DZ16K2 . . . 20
PT-DZ21K . . . 21
PT-DZ21K2 . . . 20
PT-DZ570 . . . 39
PT-DZ6700 . . . 38
PT-DZ6710 . . . 38
PT-DZ680 . . . 37
PT-DZ770 . . . 37
PT-DZ780 . . . 22
PT-DZ870 . . . 22
PT-DZ8700 . . . 36
PT-EW530 . . . 46

PT-EW540 . . . . . 43
PT-EW550 . . . . . 44
PT-EW551*4 . . . . . 45
PT-EW630 . . . . . 46
PT-EW640 . . . . . 43
PT-EW650 . . . . . 44
PT-EW651*4 . . . . . 45
PT-EW730 . . . . . 43
PT-EX12K . . . . . 47
PT-EX16K . . . . . 47
PT-EX500 . . . . . 46
PT-EX510*4 . . . . . 43
PT-EX520*4 . . . . . 44
PT-EX521*4 . . . . . 45
PT-EX600 . . . . . 46
PT-EX610 . . . . . 43
PT-EX620 . . . . . 44
PT-EX621*4 . . . . . 45
PT-EX800 . . . . . 43
PT-EZ57*4 . . . . . 44
PT-EZ570 . . . . . 46
PT-EZ580 . . . . . 43
PT-EZ590 . . . . . 44
PT-EZ591*4 . . . . . 45
PT-EZ770 . . . . . 43
PT-F100NT . . . . . 61
PT-F200NT . . . . . 61
PT-F300 . . . . . 60
PT-F300NT . . . . . 60
PT-FRQ50 . . . . . 18
PT-FRQ60 . . . . . 18
PT-FRZ50 . . . . . 19
PT-FRZ55 . . . . . 19
PT-FRZ60*4 . . . . . 19
PT-FW100NT . . . . . 61
PT-FW300 . . . . . 60
PT-FW300NT . . . . . 60
PT-FW430 . . . . . 59
PT-FW530 . . . . . 45
PT-FX400 . . . . . 59
PT-FX500*4 . . . . . 45
PT-FZ570 . . . . . 45
PT-HTQ20 . . . . . 8
PT-JW130F*4 . . . . . 72
PT-JW130G*4 . . . . . 72
PT-JW130H*4 . . . . . 72
PT-JX200F*4 . . . . . 71
PT-JX200G*4 . . . . . 71
PT-JX200H*4 . . . . . 71
PT-LB1 . . . . . 70
PT-LB1V . . . . . 70
PT-LB2 . . . . . 70
PT-LB2V . . . . . 70
PT-LB3 . . . . . 70
PT-LB330 . . . . . 67
PT-LB332*4 . . . . . 66
PT-LB353*4 . . . . . 66
PT-LB355*4 . . . . . 65
PT-LB356*4 . . . . . 64
PT-LB360 . . . . . 67
PT-LB382 . . . . . 66
PT-LB383 . . . . . 66
PT-LB385*4 . . . . . 65
PT-LB386*4 . . . . . 64
PT-LB412 . . . . . 66
PT-LB423 . . . . . 66
PT-LB425 . . . . . 65
PT-LB426 . . . . . 64
PT-LB90NT . . . . . 69
PT-LMW420 . . . . . 29
PT-LMW460 . . . . . 29
PT-LMX420 . . . . . 29
PT-LMX460 . . . . . 29
PT-LMZ420 . . . . . 29
PT-LMZ460 . . . . . 29
PT-LRW35*4 . . . . . 63
PT-LRZ35*4 . . . . . 63
PT-LW25H . . . . . 68
PT-LW280 . . . . . 67
PT-LW312 . . . . . 66
PT-LW330 . . . . . 67
PT-LW333*4 . . . . . 66
PT-LW335*4 . . . . . 65
PT-LW336*4 . . . . . 64
PT-LW362 . . . . . 66
PT-LW373 . . . . . 66
PT-LW375 . . . . . 65
PT-LW376 . . . . . 64
PT-LX26H . . . . . 68
PT-LX30H . . . . . 68
PT-LZ370 . . . . . 62
PT-MW530 . . . . . 26
PT-MW630 . . . . . 26
PT-MW730 . . . . . 26
PT-MZ10K . . . . . 24
PT-MZ11K . . . . . 23
PT-MZ13K . . . . . 24
PT-MZ14K . . . . . 23
PT-MZ16K . . . . . 24
PT-MZ17K . . . . . 23
PT-MZ20K . . . . . 23
PT-MZ570 . . . . . 26
PT-MZ670 . . . . . 26
PT-MZ680 . . . . . 25
PT-MZ682*4 . . . . . 25
PT-MZ770 . . . . . 26
PT-MZ780 . . . . . 25
PT-MZ782 . . . . . 25

PT-MZ880 . . . . . 25
PT-MZ882 . . . . . 25
PT-RCQ10 . . . . . 14
PT-RCQ80 . . . . . 14
PT-REQ10 . . . . . 11
PT-REQ12 . . . . . 11
PT-REQ15 . . . . . 11
PT-REQ80*4 . . . . . 11
PT-REZ10 . . . . . 11
PT-REZ12 . . . . . 11
PT-REZ15 . . . . . 11
PT-REZ80 . . . . . 11
PT-RQ13K . . . . . 10
PT-RQ18K . . . . . 8
PT-RQ22K . . . . . 13
PT-RQ25K . . . . . 8
PT-RQ32K . . . . . 9
PT-RQ35K . . . . . 7
PT-RQ35K2 . . . . . 7
PT-RQ45K . . . . . 8
PT-RQ50K . . . . . 6
PT-RQ6 . . . . . 11
PT-RQ7 . . . . . 11
PT-RS11K . . . . . 10
PT-RS20K . . . . . 13
PT-RS30K . . . . . 9
PT-RW330 . . . . . 34
PT-RW430 . . . . . 33
PT-RW620 . . . . . 16
PT-RW630 . . . . . 17
PT-RW730 . . . . . 16
PT-RW930 . . . . . 16
PT-RX110 . . . . . 16
PT-RZ12K . . . . . 10
PT-RZ120 . . . . . 14
PT-RZ14K . . . . . 8
PT-RZ16K . . . . . 12
PT-RZ17K . . . . . 8
PT-RZ21K . . . . . 13
PT-RZ24K . . . . . 8
PT-RZ31K . . . . . 9
PT-RZ34K . . . . . 7
PT-RZ34K2 . . . . . 7
PT-RZ370 . . . . . 34
PT-RZ44K . . . . . 8
PT-RZ470 . . . . . 33
PT-RZ475 . . . . . 32
PT-RZ570 . . . . . 31
PT-RZ575 . . . . . 31
PT-RZ6 . . . . . 11
PT-RZ660 . . . . . 16
PT-RZ670 . . . . . 17
PT-RZ690 . . . . . 15
PT-RZ7*4 . . . . . 11
PT-RZ770 . . . . . 16
PT-RZ790*4 . . . . . 15
PT-RZ870 . . . . . 17
PT-RZ890 . . . . . 15
PT-RZ970 . . . . . 16
PT-RZ990*4 . . . . . 15
PT-ST10 . . . . . 70
PT-TMW380 . . . . . 29
PT-TMX380 . . . . . 29
PT-TMZ400 . . . . . 29
PT-TW230 . . . . . 68
PT-TW231R . . . . . 68
PT-TW250*4 . . . . . 67
PT-TW340*4 . . . . . 67
PT-TW341R . . . . . 67
PT-TW342*4 . . . . . 67
PT-TW343R . . . . . 67
PT-TW350*4 . . . . . 66
PT-TW351R . . . . . 66
PT-TW370*4 . . . . . 65
PT-TW371R . . . . . 65
PT-TW380*4 . . . . . 64
PT-TW381R . . . . . 64
PT-TX310*4 . . . . . 67
PT-TX312*4 . . . . . 67
PT-TX320*4 . . . . . 66
PT-TX340*4 . . . . . 65
PT-TX350*4 . . . . . 64
PT-TX400*4 . . . . . 67
PT-TX402*4 . . . . . 67
PT-TX410*4 . . . . . 66
PT-TX430*4 . . . . . 65
PT-TX440*4 . . . . . 64
PT-VMQ65 . . . . . 27
PT-VMQ75 . . . . . 27
PT-VMQ85 . . . . . 27
PT-VMW50 . . . . . 30
PT-VMW51 . . . . . 28
PT-VMW60*4 . . . . . 30
PT-VMW61*4 . . . . . 28
PT-VMZ40*4 . . . . . 30
PT-VMZ41*4 . . . . . 28
PT-VMZ5ES . . . . . 27
PT-VMZ50 . . . . . 30
PT-VMZ51 . . . . . 28
PT-VMZ51S*4 . . . . . 28
PT-VMZ6ST . . . . . 27
PT-VMZ60 . . . . . 30
PT-VMZ61 . . . . . 28
PT-VMZ62 . . . . . 27
PT-VMZ7ST . . . . . 27
PT-VMZ71 . . . . . 28
PT-VMZ72 . . . . . 27
PT-VMZ82 . . . . . 27

PT-VW330 . . . . . 54
PT-VW340*4 . . . . . 57
PT-VW345N . . . . . 49
PT-VW350*4 . . . . . 57
PT-VW355N . . . . . 49
PT-VW360 . . . . . 56
PT-VW430 . . . . . 53
PT-VW431D . . . . . 53
PT-VW435N . . . . . 55
PT-VW440 . . . . . 53
PT-VW530*4 . . . . . 51
PT-VW535N . . . . . 49
PT-VW540*4 . . . . . 50
PT-VW545N . . . . . 48
PT-VX400 . . . . . 54
PT-VX400NT . . . . . 55
PT-VX405*4 . . . . . 53
PT-VX406*4 . . . . . 58
PT-VX41 . . . . . 54
PT-VX410*4 . . . . . 57
PT-VX415N . . . . . 49
PT-VX42*4 . . . . . 57
PT-VX420*4 . . . . . 57
PT-VX421*4 . . . . . 58
PT-VX425N . . . . . 49
PT-VX430 . . . . . 56
PT-VX431K . . . . . 56
PT-VX45*4 . . . . . 53
PT-VX46*4 . . . . . 58
PT-VX50*4 . . . . . 51
PT-VX500 . . . . . 53
PT-VX501*4 . . . . . 53
PT-VX505N . . . . . 55
PT-VX51*4 . . . . . 50
PT-VX510 . . . . . 53
PT-VX60*4 . . . . . 51
PT-VX600*4 . . . . . 51
PT-VX605N . . . . . 49
PT-VX61*4 . . . . . 50
PT-VX610 . . . . . 50
PT-VX615N . . . . . 48
PT-VZ470*4 . . . . . 52
PT-VZ570*4 . . . . . 51
PT-VZ575N . . . . . 49
PT-VZ580*4 . . . . . 50
PT-VZ585N . . . . . 48
TH-D10000 . . . . . 40
TH-D3500 . . . . . 42
TH-D5600 . . . . . 42
TH-D7700 . . . . . 41
TH-DW10000 . . . . . 40
TH-DW5000 . . . . . 42
TH-DW7000 . . . . . 41

*1: Note on model groups
The difference in the type of information that can be accessed for “rich information models” and “basic information models” is as follows.

○: Supported ×: Not supported

| Item | Model categorization based on accessible information difference | |
|---|---|---|
| | Rich information model | Basic information model |
| Group Name | ○ | ○ |
| IP Address | ○ | ○ |
| Shutter (AV Mute) | ○ | ○ |
| Model Name | ○ | ○ |
| Serial Number | ○* | × |
| Selected input | ○ | ○ |
| Power | ○ | ○ |
| Selected LIGHT | ○* | × |
| LIGHT Power / Operating mode | ○ | × |
| Signal Freq. | ○ | × |
| Main Version | ○ | × |
| Network Version | ○* | × |
| Power on hours | ○ | ○* |
| Temperature | ○* | × |
| LIGHT status | ○* | ○* |
| Fan status | ○* | × |

* May not be accessible depending on the device.

*2: Model number of product sold in Japan. This will differ for products sold in other regions.
*3: Model number of product sold in regions other than Japan. This will differ for products sold in Japan.
*4: Not sold in Japan.

### Notes

The software is not compatible with any device models not appearing in this “Device model list.”

## Peripheral device list

■ Peripheral devices

Media Processor FMP Series

ET-FMP50 . . . . . 73
ET-FMP20 . . . . . 73
ET-SBFMP10 . . . . . 73

Network camera

Panasonic BB-S Series, DG-S Series, WV-S Series, AW-UN70 Series, AW-HN130 Series, AW-HN40 Series, AW-HE130 Series, AW-HE40 Series, and AW-HR140 network cameras are supported. Allows the video shown on a display (projector or flat-panel display) to be checked remotely through a camera.

## ■PT-RQ50K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/E/X/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | dispadmin*1 |
| | | Password | @Panasonic*2 |
| | PJLink | Password | @Panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | — |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | ○ |
| | Remote preview function or remote preview lite | | ○ |
| | Simultaneous multi-device firmware update function | | ○*3 |
| | Push notification function | | ○*3 |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

*3: This requires the software main version of the projector to be Ver. 3.07 or higher. Versions below Ver. 3.07 are not supported.

## ■PT-RQ35K2 / PT-RZ34K2
## ■PT-RQ35K / PT-RZ34K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/E/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | Set by user*1 |
| | | Password | Set by user*1 |
| | PJLink | Password | Set by user*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | — |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | ○ |
| | Remote preview function or remote preview lite | | ○ |
| | Simultaneous multi-device firmware update function | | ○ |
| | Push notification function | | ○*2 |

*1: The username and password of the administrator account must be configured.

*2: Access the [Detailed set up] → [Status notification] page on the Web Control screen of the projector unit, and enable the push notification function.

## ■PT-RQ45K / PT-RZ44K
## ■PT-RQ25K / PT-RQ18K / PT-RZ24K / PT-RZ17K ■PT-RZ14K
## ■PT-HTQ20

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: D/E/EJ/G/X/(blank))

Model group: **Rich information model** ○: Supported ×: Not supported —: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | Set by user*1 |
| | | Password | Set by user*1 |
| | PJLink | Password | Set by user*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | ○ |
| | Remote preview function or remote preview lite | | ○ |
| | Simultaneous multi-device firmware update function | | ○ |
| | Push notification function | | ○ |

*1: The username and password of the administrator account must be configured.

## ■PT-RQ32K / PT-RZ31K / PT-RS30K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | ○*3 |
| | Push notification function | | ○*3 |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

*3: PT-RQ32K requires the software main version of the projector to be Ver. 4.03 or higher. Versions below Ver. 4.03 are not supported.
PT-RZ31K / PT-RS30K requires the software main version of the projector to be Ver. 3.15 or higher. Versions below Ver. 3.15 are not supported.

## ■PT-RQ13K / PT-RZ12K / PT-RS11K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-REQ15 / PT-REQ12 / PT-REQ10 / PT-REQ80
## ■PT-REZ15 / PT-REZ12 / PT-REZ10 / PT-REZ80
## ■PT-RQ7 / PT-RQ6 / PT-RZ7 / PT-RZ6

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: D/E/EJ/J/UG/(blank), lens: (blank)/L, cabinet color: B/W)

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | Set by user*1 |
| | | Password | Set by user*1 |
| | PJLink | Password | Set by user*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | ○ |
| | Remote preview function or remote preview lite | | ○ |
| | Simultaneous multi-device firmware update function | | ○ |
| | Push notification function | | ○ |

*1: The username and password of the administrator account must be configured.

## ■PT-RZ16K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
Model group: **Rich information model** ○: Supported ×: Not supported —: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | Set by user*1 |
| | | Password | Set by user*1 |
| | PJLink | Password | Set by user*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | ○ |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | ○*2 |
| | Push notification function | | ○*2 |

*1: The username and password of the administrator account must be configured.
*2: This requires the software main version of the projector to be Ver. 2.05 or higher. Versions below Ver. 2.05 are not supported.

## ■PT-RQ22K / PT-RZ21K / PT-RS20K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | dispadmin*1 |
| | | Password | @Panasonic*2 |
| | PJLink | Password | @Panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | ○ |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | ○*3 |
| | Push notification function | | ○*3 |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

*3: PT-RZ21K / PT-RS20K requires the software main version of the projector to be Ver. 4.06 or higher. Versions below Ver. 4.06 are not supported.
PT-RQ22K requires the software main version of the projector to be Ver. 5.06 or higher. Versions below Ver. 5.06 are not supported.

## ■PT-RCQ10 / PT-RCQ80
## ■PT-RZ120

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: A/D/E/J/X/(blank), lens: (blank)/L, cabinet color: B/W)

Model group: **Rich information model** ○: Supported ×: Not supported —: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | dispadmin*1 |
| | | Password | @Panasonic*2 |
| | PJLink | Password | @Panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | ○ |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-RZ990 / PT-RZ890 / PT-RZ790 / PT-RZ690

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/J/(blank), lens: (blank)/L, cabinet color: B/W/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | Set by user*1 |
| | | Password | Set by user*1 |
| | PJLink | Password | Set by user*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | ○ |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: The username and password of the administrator account must be configured.

## ■PT-RZ970 / PT-RW930 / PT-RX110 / PT-RZ770 / PT-RW730 / PT-RZ660 / PT-RW620

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: A/D/E/J/T/U/(blank), lens: (blank)/L, cabinet color: B/K/W/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-RZ670 / PT-RW630 ■PT-RZ870

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: A/D/E/J/T/U/(blank), lens: (blank)/L, cabinet color: B/K/W/(blank))

Model group: **Rich information model** ○: Supported ×: Not supported —: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-FRQ60
## ■PT-FRQ50

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/W)

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | Set by user*1 |
| | | Password | Set by user*1 |
| | PJLink | Password | Set by user*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | ○ |
| | Remote preview function or remote preview lite | | ○ |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: The username and password of the administrator account must be configured.

## ■PT-FRZ60 / PT-FRZ50 / PT-FRZ55

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/W)

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | Set by user*1 |
| | | Password | Set by user*1 |
| | PJLink | Password | Set by user*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1:　The username and password of the administrator account must be configured.

## ■PT-DZ21K2 / PT-DS20K2 / PT-DW17K2 / PT-DZ16K2

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: A/D/E/J/T/U/(blank), lens: (blank)/L, cabinet color: B/K/W/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-DZ21K / PT-DS20K / PT-DW17K / PT-DZ16K
## ■PT-DZ13K / PT-DS12K / PT-DW11K / PT-DZ10K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: A/D/E/J/T/U/(blank), lens: (blank)/L, cabinet color: B/K/W/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-DZ870 / PT-DW830 / PT-DX100　■PT-DZ780 / PT-DW750 / PT-DX820

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: A/D/E/J/T/U/(blank), lens: (blank)/L, cabinet color: B/K/W/(blank))

Model group: **Rich information model**　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-MZ20K / PT-MZ17K / PT-MZ14K / PT-MZ11K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/E/EJ/J/X/(blank), lens: L, cabinet color: B/W)

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | Set by user*1 |
| | | Password | Set by user*1 |
| | PJLink | Password | Set by user*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | ○ |
| | Remote preview function or remote preview lite | | ○ |
| | Simultaneous multi-device firmware update function | | ○ |
| | Push notification function | | ○ |

*1: The username and password of the administrator account must be configured.

## ■PT-MZ16K / PT-MZ13K / PT-MZ10K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/E/J/X/(blank), lens: L, cabinet color: B/W)

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | dispadmin*1 |
| | | Password | @Panasonic*2 |
| | PJLink | Password | @Panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-MZ882 / PT-MZ782 / PT-MZ682
## ■PT-MZ880 / PT-MZ780 / PT-MZ680

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/W)

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | Set by user*1 |
| | | Password | Set by user*1 |
| | PJLink | Password | Set by user*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | ○ |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: The username and password of the administrator account must be configured.

## ■PT-MZ670 / PT-MW630 / PT-MZ570 / PT-MW530　■PT-MZ770 / PT-MW730

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: A/D/J/(blank), lens: (blank)/L, cabinet color: (blank))

Model group: **Rich information model**　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | dispadmin*1 |
| | | Password | @Panasonic*2 |
| | PJLink | Password | @Panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | ○ |
| | Wireless settings display function | | ○*3 |
| | DATA CLONING | | ○ |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

*3: Optional wireless module (ET-WM300) is required.

## ■PT-VMQ85 / PT-VMQ75 / PT-VMQ65
## ■PT-VMZ82 / PT-VMZ72 / PT-VMZ62 / PT-VMZ7ST / PT-VMZ6ST
## ■PT-VMZ5ES

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/W/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | Set by user*1 |
| | | Password | Set by user*1 |
| | PJLink | Password | Set by user*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: The username and password of the administrator account must be configured.

## ■PT-VMZ71 / PT-VMZ61 / PT-VMZ51 / PT-VMZ51S / PT-VMZ41 / PT-VMW61 / PT-VMW51
## ■PT-CMZ50

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/(blank))

Model group: **Rich information model** ○: Supported ×: Not supported —: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | Set by user*1 |
| | | Password | Set by user*1 |
| | PJLink | Password | Set by user*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: The username and password of the administrator account must be configured.

## ■PT-LMZ460 / PT-LMZ420 / PT-LMW460 / PT-LMW420 / PT-LMX460 / PT-LMX420 / PT-TMZ400 / PT-TMW380 / PT-TMX380

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/J/T/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | Set by user*1 |
| | | Password | Set by user*1 |
| | PJLink | Password | Set by user*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: The username and password of the administrator account must be configured.

## ■PT-VMZ60 / PT-VMZ50 / PT-VMZ40 / PT-VMW60 / PT-VMW50

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | dispadmin*1 |
| | | Password | @Panasonic*2 |
| | PJLink | Password | @Panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-RZ575 / PT-RZ570

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: A/D/J/T/(blank), cabinet color: B/W)

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-RZ475

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○*3 |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

*3: If the temperature of the projector's surroundings is elevated, light output may be reduced in order to protect the projector unit. If this software is used for the brightness control of multiple projectors, please ensure that as far as possible the temperature of the surroundings is the same for all projectors.

## ■PT-RZ470 / PT-RW430

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: E/EA/U/(blank), cabinet color: K/W/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○*3 |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

*3: If the temperature of the projector's surroundings is elevated, light output may be reduced in order to protect the projector unit. If this software is used for the brightness control of multiple projectors, please ensure that as far as possible the temperature of the surroundings is the same for all projectors.

## ■PT-RZ370 / PT-RW330

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-DZ12000 / PT-D12000 / PT-DW100

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: E/U/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not required (LAN terminal installed)*1 |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*2 |
| | | Password | panasonic*3 |
| | PJLink | Password | panasonic*3 |
| Projector settings | Network standby | | ON |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | 1024 |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | — |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: Of the commercially available expansion boards, the ET-MD77NT network board is not supported.
With expansion boards other than the ET-MD77NT, the network function on the expansion board side cannot be used (DVI, SDI, and other inputs are enabled).
The ET-MD100SD4 digital signal input board (for dual link HD-SDI) is supported.

*2: This is the user name provided at the time of shipment.

*3: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-DZ8700 / PT-DS8500 / PT-DW8300 / PT-DZ110XE / PT-DS100XE / PT-DW90XE / PT-DW105XEA

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: E/U/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | ○ |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-DZ770 / PT-DW740 / PT-DX810　■PT-DZ680 / PT-DW640 / PT-DX610

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: E/U/(blank), cabinet color: K/S/(blank), lens: (blank)/L)

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-DZ6710 / PT-DZ6700 / PT-DW6300 / PT-D6000 / PT-D5000
## ■PT-DW730 / PT-DX800

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: E/U/(blank), cabinet color: K/S/(blank), lens: (blank)/L)

Model group: **Rich information model** ○: Supported ×: Not supported —: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-DZ570 / PT-DW530 / PT-DX500

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: E/U/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■TH-DW10000 / TH-D10000 / PT-DW10000 / PT-D10000

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: E/U)

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not required (LAN terminal installed)*1 |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | user1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | — |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | × |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: Of the commercially available expansion boards, the ET-MD77NT network board is not supported.
With expansion boards other than the ET-MD77NT, the network function on the expansion board side cannot be used (DVI, SDI, and other inputs are enabled).
The ET-MD100SD4 digital signal input board (for dual link HD-SDI) is supported. (except for TH-D10000 and PT-D10000)

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■TH-D7700 / TH-DW7000 / PT-D7700 / PT-DW7000

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: E/U, cabinet color: K/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Expansion board required*1 |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | user1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | — |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | × |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: One of the following commercially available expansion boards with a network function is required.
Network board: ET-MD77NT
Digital signal input board (for SD-SDI): ET-MD77SD1
Digital signal input board (for HD-SDI): ET-MD77SD3
Digital signal input board (for DVI): ET-MD77DV

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-D5700 / PT-D4000 / PT-DW5100
## ■TH-D5600 / PT-D5600 / TH-DW5000 / PT-DW5000 ■TH-D3500 / PT-D3500

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: E/U/(blank), lens: (blank)/L)

Model group: **Rich information model** ○: Supported ×: Not supported —: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | user1 |
| | | Password | panasonic*1 |
| | PJLink | Password | panasonic*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | — |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | × |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-EZ770 / PT-EW730 / PT-EX800
## ■PT-EZ580 / PT-EW640 / PT-EW540 / PT-EX610 / PT-EX510

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: A/D/J/K/T/Z/(blank), lens: (blank)/L)

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-EZ590 / PT-EW650 / PT-EW550 / PT-EX620 / PT-EX520 / PT-EZ57

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: D/J/K/T/(blank), lens: (blank)/L)

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-EZ591 / PT-EW651 / PT-EW551 / PT-EX621 / PT-EX521
## ■PT-FZ570 / PT-FW530 / PT-FX500

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/J/K/T/(blank), lens: (blank)/L)

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-EZ570 / PT-EW630 / PT-EW530 / PT-EX600 / PT-EX500

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal, Network |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-EX16K ■PT-EX12K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: E/U/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | — |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-VZ585N / PT-VW545N / PT-VX615N

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: D/J/T/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | Normal |
| | Standby mode | | — |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | ○ |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-VZ575N / PT-VW535N / PT-VX605N ■PT-VW355N / PT-VX425N ■PT-VW345N / PT-VX415N

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/J/T/Z/(blank))

Model group: **Rich information model** ○: Supported ×: Not supported —: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | ON |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | ○ |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-VZ580 / PT-VW540 / PT-VX610 / PT-VX61 / PT-VX51

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: D/J/K/K1/T/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | ON |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-VZ570 / PT-VW530 / PT-VX600　■PT-VX60 / PT-VX50

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/T/(blank))

Model group: **Rich information model**　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | ON |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-VZ470

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: D/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | ON |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-VW440 / PT-VX510 ■PT-VW431D
## ■PT-VW430 / PT-VX501 / PT-VX500 / PT-VX405 / PT-VX45

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: E/EA/KEA/U/(blank))

Model group: **Rich information model** ○: Supported ×: Not supported —: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | ON |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Network |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-VW330 / PT-VX400 ■PT-VX41

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: E/EA/KEA/U/(blank))

Model group: **Rich information model** ○: Supported ×: Not supported —: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | ON |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Network |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-VW435N / PT-VX505N　■PT-VX400NT

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | ON |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Network |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-VW360 / PT-VX430 / PT-VX431K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: D/J/T/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | dispadmin*1 |
| | | Password | @Panasonic*2 |
| | PJLink | Password | @Panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | ON |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-VW350 / PT-VX420 ■PT-VW340 / PT-VX410 / PT-VX42

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/EA/J/T/Z/(blank))

Model group: **Rich information model** ○: Supported ×: Not supported —: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | ON |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-VX421 ■PT-VX406 / PT-VX46

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/EA/J/T/Z/(blank))

Model group: **Rich information model** ○: Supported ×: Not supported —: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | ON |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-FW430 / PT-FX400

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | ON |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-FW300NT / PT-FW300 / PT-F300NT / PT-F300

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | ON |
| | Network control | | ON |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | — |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-FW100NT / PT-F100NT　■PT-F200NT

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | user1 |
| | | Password | No password set*1 |
| | PJLink | Password | No password set*1 |
| Projector settings | Network standby | | ON |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | — |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | × |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the setting provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-LZ370

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | ON |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-LRZ35 / PT-LRW35

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: U/(blank))

Model group: **Basic information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | dispadmin*1 |
| | | Password | Set by user*1 |
| | PJLink | Password | Set by user*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | × |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | × |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: The username and password of the administrator account must be configured.

## ■PT-LB426 / PT-LB386 / PT-LB356 / PT-LW376 / PT-LW336
## ■PT-TW381R / PT-TW380 / PT-TX440 / PT-TX350

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/J/T/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | Set by user*1 |
| | | Password | Set by user*1 |
| | PJLink | Password | Set by user*1 |
| Projector settings | Network standby | | — |
| | Network control | | ON |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: The username and password of the administrator account must be configured.

## ■PT-LW375 / PT-LW335 / PT-LB425 / PT-LB385 / PT-LB355
## ■PT-TW371R / PT-TW370 / PT-TX430 / PT-TX340

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/J/K/T/U/(blank))

Model group: **Basic information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin |
| | | Password | admin1*1 |
| | PJLink | Password | admin1*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | × |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | × |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-LW373 / PT-LW333 / PT-LB423 / PT-LB383 / PT-LB353
## ■PT-TW351R / PT-TW350 / PT-TX410 / PT-TX320
## ■PT-LW362 / PT-LW312 / PT-LB412 / PT-LB382 / PT-LB332

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: D/J/(blank))

Model group: **Basic information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin |
| | | Password | admin1*1 |
| | PJLink | Password | admin1*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | × |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | × |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-LW330*2 / PT-LW280*2 / PT-LB360*2 / PT-LB330*2
## ■PT-TW343R / PT-TW342 / PT-TX402 / PT-TX312
## ■PT-TW341R*2 / PT-TW340*2 / PT-TW250*2 / PT-TX400*2 / PT-TX310*2

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: D/J/(blank))

Model group: **Basic information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin |
| | | Password | admin1*1 |
| | PJLink | Password | admin1*1 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | × |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | × |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.
*2: Only devices with serial numbers that start with “B” or “DB53” are supported.

## ■PT-LW25H / PT-LX30H / PT-LX26H　■PT-TW231R / PT-TW230

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | ON |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Network |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-LB90NT

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | ON |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■PT-LB3 / PT-LB2V / PT-LB2 / PT-LB1V / PT-LB1 / PT-ST10

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.
＊ Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**　　○: Supported　×: Not supported　—: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | ON |
| | WEB control | | — |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | — |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal |
| Monitoring and control functions | Auto search (local network) function | | × |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | × |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | × |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.
*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

## ■NTN91003 / NTN91002 ■PT-JX200F / PT-JX200G / PT-JX200H

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/E/K/T/U, cabinet color: B/W)

Model group: **Rich information model** ○: Supported ×: Not supported —: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal*3 |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | ○ |
| | Contents list delivery function | | × |
| | Wireless settings display function | | ○ |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

*3: When set to “Network” or “ECO”, information acquisition and control will be disabled.

## ■NTN91001 / NTN91000 ■PT-JW130F / PT-JW130G / PT-JW130H

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

＊ Alphabet letters at end (place of destination: D/E/K/T/U, cabinet color: B/W)

Model group: **Rich information model** ○: Supported ×: Not supported —: Not available

| | | | Setting / compatibility |
|---|---|---|---|
| Optional accessories | Expansion boards | | Not used |
| Connection to projector | IP address | | Only fixed IP address supported |
| | WEB control screen login | User name | admin1*1 |
| | | Password | panasonic*2 |
| | PJLink | Password | panasonic*2 |
| Projector settings | Network standby | | — |
| | Network control | | |
| | WEB control | | ON |
| | Command control | | — |
| | WEB port / Command port | | — |
| | PJLink control | | ON |
| | ECO management | | |
| | Standby mode | | — |
| | Standby mode | | Normal*3 |
| Monitoring and control functions | Auto search (local network) function | | ○ |
| | Device status monitoring function (Simplified) | | ○ |
| | Device location information registering function (Map monitoring function) | | ○ |
| | Command transmission function | | ○ |
| | Brightness control function | | × |
| | ECO management function | | ○ |
| | Maintenance log save function | | × |
| | Contents list delivery function | | × |
| | Wireless settings display function | | ○ |
| | DATA CLONING | | × |
| | Remote preview function or remote preview lite | | × |
| | Simultaneous multi-device firmware update function | | × |
| | Push notification function | | × |

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

*3: When set to “Network” or “ECO”, information acquisition and control will be disabled.

## ■ET-FMP50 / ET-FMP20 / ET-SBFMP10

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

○: Supported ×: Not supported —: Not available

| | | Setting / compatibility |
|---|---|---|
| Connection to Media Processor | IP address | Only fixed IP address supported |
| | User name | Set by user*1 |
| | Password | Set by user*1 |
| Functions | Media Processor power status display | ○ |
| | WEB control screen display | ○ |
| | Serial number display | ○ |

*1: The username and password of the account must be configured.